INFINITE DIMENSIONS GAMES

Wightwood Abbey Ruined Rookery Tower

Instructions



General Information

Prints: **5**

Dimensions: **approx. 7”D x 9”W x 11”H assembled when printed at 100% (28mm or 1/60 scale)**

Printer Requirement: **FDM Printer with a minimum 200mm x 200mm (8”x8”) bed.**

Preparation

Thank you for purchasing the Wightwood Abbey Ruined Rookery Tower

The Wightwood Abbey Ruined Rookery Tower is part of the Wightwood Abbey line of terrain, but is set apart by its aesthetic and its place in the history of the abbey. As a play piece, it provides three distinct levels of play with multiple other places in between those levels where figures can be placed. The second level features a functional door and each level has a variety of cracks and openings where defends can shoot out at attackers and attackers can breach the walls. A ladder is included in the set to help characters move from level to level in the interior of the tower.

INFINITE DIMENSIONS GAMES

1. Download and unzip your files and keep them in their own well labeled folder for ease of use.
2. We recommend backing up your purchases as they will be accessible for download only for a limited period of time after your purchase.
3. Print the pieces
4. Clean and prep each piece.
5. Spray with a primer
6. Paint

For details on how to do these steps please check our YouTube Channel

Remember that your purchase is for your own personal use only as per the Terms of Use. Please do not distribute the files or prints.

Printing Tips

For bed adhesion we strongly recommend printing with a brim of 4 mm or greater.

Every printer is different but in general here are the main settings to pay attention to:

- Bed Adhesion ON (we recommend using a brim)
- Support Material OFF (all our parts have built in support).
- Layer Height of .2mm or less (we recommend setting the first layer to .3)
- Retraction amount and speed
- Acceleration and jerk settings
- Overall Print speed (slower the better)

Notes

Scaling down: To print at 15mm scale reduce all pieces by approximately 50%

Please note that some functionality may not work at this scale. Also some details may not come out or will need to be cleaned.

Assembling: Some pieces might need to be filed down or trimmed with a hobby knife.

Doors are installed by inserting a piece of 1.75mm filament into the hole to pin the door in place. Make sure to carefully clean out the door hinge gaps before installing door. Do not force door if it is resisting but remove and further file and clean out the connecting points. Each door is unique so please make sure to use the right door in the right place.

For more assembly information and to watch our assemble video visit:

www.infinitedimensions.ca/resources

INFINITE DIMENSIONS GAMES

Prints and Filenames



#	File Name	Piece Name
1	WWA_RKRY_LV1A	Rookery Base
2	WWA_RKRY_LV1B	Rookery Level 1

3	WWA_RKRY_LV2	Rookery Level 2
4	WWA_RKRY_LV3	Rookery Level 3
5	WWA_RKRY_DR	Rookery Door
6	WWA_RKRY_LDDR	Rookery Ladder